



# **GR5xx Power Consumption Profile Example Application**

**Version: 3.1**

**Release Date: 2023-11-06**

**Copyright © 2023 Shenzhen Goodix Technology Co., Ltd. All rights reserved.**

Any excerption, backup, modification, translation, transmission or commercial use of this document or any portion of this document, in any form or by any means, without the prior written consent of Shenzhen Goodix Technology Co., Ltd. is prohibited.

## **Trademarks and Permissions**

**GOODiX** and other Goodix trademarks are trademarks of Shenzhen Goodix Technology Co., Ltd. All other trademarks and trade names mentioned in this document are the property of their respective holders.

## **Disclaimer**

Information contained in this document is intended for your convenience only and is subject to change without prior notice. It is your responsibility to ensure its application complies with technical specifications.

Shenzhen Goodix Technology Co., Ltd. (hereafter referred to as “Goodix”) makes no representation or guarantee for this information, express or implied, oral or written, statutory or otherwise, including but not limited to representation or guarantee for its application, quality, performance, merchantability or fitness for a particular purpose. Goodix shall assume no responsibility for this information and relevant consequences arising out of the use of such information.

Without written consent of Goodix, it is prohibited to use Goodix products as critical components in any life support system. Under the protection of Goodix intellectual property rights, no license may be transferred implicitly or by any other means.

## **Shenzhen Goodix Technology Co., Ltd.**

Headquarters: Floor 12-13, Phase B, Tengfei Industrial Building, Futian Free Trade Zone, Shenzhen, China

TEL: +86-755-33338828      Zip Code: 518000

Website: [www.goodix.com](http://www.goodix.com)

# Preface

## Purpose

This document introduces how to use and verify a power consumption measurement example in the Bluetooth Low Energy (Bluetooth LE) GR5xx Software Development Kit (SDK), to help users quickly get started with secondary development.

## Audience

This document is intended for:

- Device user
- Developer
- Test engineer
- Hobbyist developer
- Technical writer

## Release Notes

This document is the third release of *GR5xx Power Consumption Profile Example Application*, corresponding to Bluetooth LE GR5xx System-on-Chip (SoC) series.

## Revision History

Version	Date	Description
1.0	2023-01-10	Initial release
3.0	2023-03-30	Updated descriptions about GR5xx SoCs.
3.1	2023-11-06	Updated the approaches for obtaining GProgrammer and GRTtoolbox.

# Contents

<b>Preface</b> .....	<b>I</b>
<b>1 Introduction</b> .....	<b>1</b>
<b>2 Profile Overview</b> .....	<b>2</b>
<b>3 Initial Operation</b> .....	<b>3</b>
3.1 Preparation.....	3
3.2 Firmware Programming.....	3
3.3 Test and Verification.....	3
<b>4 Application Details</b> .....	<b>7</b>
4.1 Running Procedures.....	7
4.2 Major Code.....	7
4.2.1 Power Management Configuration.....	7
4.2.2 Command Parsing, Execution, and Response.....	9
4.2.3 Enabling Notify.....	10

# 1 Introduction

GR5xx Power Consumption Profile (PCP) example allows users to set parameters in real time through mobile phones, to configure power consumption measurement scenarios.

This document introduces how to use and verify a custom Goodix PCP example in the GR5xx Software Development Kit (SDK).

Before getting started, you can refer to the following documents.

Table 1-1 Reference documents

Name	Description
GR5xx Sample Service Application and Customization	Introduces how to apply and customize Goodix Sample Service in developing Bluetooth LE applications based on GR5xx SDK.
Developer guide of the specific GR5xx SoC	Introduces GR5xx SDK and how to develop and debug applications based on the SDK.
Bluetooth Core Spec	Offers official Bluetooth standards and core specification from Bluetooth SIG.
Bluetooth GATT Spec	Provides details about Bluetooth profiles and services. Available at <a href="https://www.bluetooth.com/specifications/gatt">https://www.bluetooth.com/specifications/gatt</a> .
J-Link/J-Trace User Guide	Provides J-Link operational instructions. Available at <a href="https://www.segger.com/downloads/jlink/UM08001_JLink.pdf">https://www.segger.com/downloads/jlink/UM08001_JLink.pdf</a> .
Keil User Guide	Offers detailed Keil operational instructions. Available at <a href="https://www.keil.com/support/man/docs/uv4/">https://www.keil.com/support/man/docs/uv4/</a> .

## 2 Profile Overview

The Power Consumption Service (PCS) is defined in PCP. It is customized by Goodix, the 128-bit vendor-specific UUID of which is A6ED0501-D344-460A-8075-B9E8EC90D71B, to transmit data and commands and receive responses.

PCS includes two characteristics:

- TX: Transmit data.
- Setting: Send commands to customize power consumption measurement scenarios and receive responses of command execution.

The characteristics are described in detail as follows.

Table 2-1 PCS characteristics

Characteristic	UUID	Type	Support	Security	Property
TX	A6ED0202-D344-460A-8075-B9E8EC90D71B	128 bits	Mandatory	None	Notify
Setting	A6ED0203-D344-460A-8075-B9E8EC90D71B	128 bits	Mandatory	None	Write, Indicate

## 3 Initial Operation

This chapter introduces how to run and verify the PCP example in the GR5xx SDK.

### Note:

SDK\_Folder is the root directory of the GR5xx SDK in use.

### 3.1 Preparation

Perform the following tasks before running a PCP example.

- **Hardware preparation**

Table 3-1 Hardware preparation

Name	Description
Development board	Starter Kit Board (SK Board) of the corresponding SoC
Connection cable	USB Type C cable (Micro USB 2.0 cable for GR551x SoCs)
Keysight N6705C	DC power analyzer launched by Keysight

- **Software preparation**

Table 3-2 Software preparation

Name	Description
Windows	Windows 7/Windows 10
J-Link driver	A J-Link driver. Available at <a href="https://www.segger.com/downloads/jlink/">https://www.segger.com/downloads/jlink/</a> .
Keil MDK5	An integrated development environment (IDE). MDK-ARM Version 5.20 or later is required. Available at <a href="https://www.keil.com/download/product/">https://www.keil.com/download/product/</a> .
GRToolbox (Android)	A Bluetooth LE debugging tool. Available at <a href="https://www.goodix.com/en/software_tool/grtoolbox">https://www.goodix.com/en/software_tool/grtoolbox</a> .
GProgrammer (Windows)	A programming tool. Available at <a href="https://www.goodix.com/en/software_tool/gprogrammer_ble">https://www.goodix.com/en/software_tool/gprogrammer_ble</a> .
Keysight 14585A	Power control and analysis software launched by Keysight

### 3.2 Firmware Programming

The source code of the PCP example is in SDK\_Folder\projects\ble\ble\_peripheral\ ble\_app\_pcs. You can download *ble\_app\_pcs.bin* to the SK Board. For details, see *GProgrammer User Manual*.

### Note:

The *ble\_app\_pcs.bin* is in SDK\_Folder\projects\ble\ble\_peripheral\ble\_app\_pcs\build.

### 3.3 Test and Verification

For how to set up a hardware environment for test and verification, refer to "Environment Setup" in the power mode and power consumption measurement application note of the specific SoC.

When the SK Board downloaded with *ble\_app\_pcs.bin* is powered on, the system enters Ultra Deep Sleep Mode. After reset, press **OK** on the board for more than 3 seconds to allow the system to initiate advertising, which lasts for 30 seconds. If the board is not connected to other devices, the system then enters Sleep Mode again due to advertising timeout; if the board is connected to other devices, the system also enters Sleep Mode when the board is in disconnected state, until the system wakes up. Press **OK** to wake the system up from Sleep Mode.

 **Note:**

In the GR5xx PCP example, the macro definition for the **OK** button in the software is APP\_KEY\_OK\_PIN. However, the actual button silkscreen corresponding to the **OK** button varies depending on the specific development board circuit adopted for the corresponding GR5xx SoC. For instance, GR551x uses **S1**, and GR5526 uses **K1**. For other SoC series, refer to the corresponding development board schematics. In this document, the **OK** button is used for all GR5xx SoCs for convenience.

The steps are provided as follows:

1. Establish connection and set measurement scenarios.

Establish connection by using the mobile tool GRToolbox. Detailed steps are shown as follows:

- (1). Run GRToolbox, and select **Application > PCS**.
- (2). Tap **CONNECT** and then start scanning target devices. Discover a device with the advertising name **Goodix\_Power** (the advertising name can be modified in the *user\_app.c* file).




Figure 3-1 Discovering **Goodix\_Power**

**Note:**

Screenshots of GRToolbox in this document are for reference only, to help users better understand the software operation. In the case of interface differences due to version changes, the interface of GRToolbox in practice shall prevail.

- (3). Tap **Goodix\_Power** to establish connection, and then enter the setting page to set related power consumption measurement scenarios, including **Adv Interval**, **Adv Data**, **Connection Param**, **PHY Mode**, **Tx Power**, and **Enable Notify**, as shown in the figure below. Settings of **Adv Interval**, **Adv Data**, and **Tx Power** are valid only if advertising is restarted after the current connection is broken; settings of **Connection Param** and **PHY Mode** are valid only for the current connection. If no advertising name or service UUID is discovered, tap **Last Connected Device** to search devices based on the previous device MAC address.




Figure 3-2 Setting page of power consumption measurement scenarios

- (4). If the connection is broken, press **OK** on the SK Board, to allow the device to re-initiate advertising with the configured data length and connection interval.

2. Measure GR5xx power consumption.

After measurement scenarios are set, measure GR5xx power consumption in different scenarios with Keysight installed on the PC. The following screenshots show the test results of a GR5526 SoC and are for reference only.

Scenario 1: advertising state at an interval of 1s



Figure 3-3 Power consumption measurement scenario 1

Scenario 2: connecting state at an interval of 200 ms




Figure 3-4 Power consumption measurement scenario 2

Users can set other power consumption measurement scenarios on demand.

## 4 Application Details

This chapter introduces the running procedures and major code of the PCP example.

### 4.1 Running Procedures

When the board downloaded with PCP example is powered on, the system initializes peripherals and power management, Bluetooth LE Protocol Stack, and PCS successively. The main procedures are shown in the figure below:




Figure 4-1 Running procedures

## 4.2 Major Code

The following parts elaborate on major code related to interactions between the SK Board and GRToolbox.

### 4.2.1 Power Management Configuration

1. Configure the power management mode of the GR5xx System-on-Chip (SoC) to Sleep Mode (PMR\_MGMT\_SLEEP\_MODE), and configure an external wakeup source (on-board **OK** button) to wake up the GR5xx SoC and enable advertising.

**Path:** user\_platform\user\_periph\_setup.c under the project directory

**Name:** wkup\_key\_init(), app\_periph\_init();

```
static void wkup_key_init(void)
{
    ...
    s_gpiote_param.pin = APP_KEY_OK_PIN;
    ...

    app_gpiote_init(&s_gpiote_param, 1);
}
```

```
void app_periph_init(void)
{
    ...
    wkup_key_init();
    pwr_mgmt_mode_set(PMR_MGMT_SLEEP_MODE);
}
```

2. The following function determines whether the system enters Ultra Deep Sleep Mode or implements normal task logics after booting. It is called in the main() function.

**Path:** user\_platform\user\_periph\_setup.c under the project directory

**Name:** is\_enter\_ultra\_deep\_sleep();

```
bool is_enter_ultra_deep_sleep(void)
{
    if (APP_IO_PIN_RESET != app_io_read_pin(APP_IO_TYPE_AON, APP_KEY_OK_PIN))
    {
        return true;
    }

    return false;
}
```

3. The main() function determines the procedure branches and low power management of the system after booting.

```
int main(void)
{
    app_periph_init();

    if (is_enter_ultra_deep_sleep())
    {
        pwr_mgmt_ultra_sleep(0);
    }
    // Initialize ble stack.
    ble_stack_init(ble_evt_handler, &heaps_table);
    while (1)
    {
        pwr_mgmt_schedule();
    }
}
```

}

## 4.2.2 Command Parsing, Execution, and Response

When Setting Characteristic Value receives a command from the peer device, it reports events and related information to the application layer. The `pcs_param_parse()` function then can be used to parse, execute, and respond to the command. This section introduces how to set the scenarios for power consumption measurement by taking the settings of advertising interval and advertising data as examples.

### 1. Set advertising interval.

Set the advertising interval value, and respond to the peer device. This value takes effect on the next advertising. For specific code, see processing code of `PCS_SETTING_TYPE_ADV_INTERVAL` event in the `pcs_param_parse()` function.

**Path:** `user_app\user_app.c` under the project directory

**Name:** `pcs_param_parse()`

```
void pcs_param_parse(uint8_t conn_idx, uint8_t *p_data, uint16_t length)
{
    ...
    switch (p_data[0])
    {
        case PCS_SETTING_TYPE_ADV_INTERVAL:
            s_gap_adv_param.adv_intv_max = BUILD_U16(p_data[1], p_data[2]);
            s_gap_adv_param.adv_intv_min = BUILD_U16(p_data[1], p_data[2]);
            response[0] = PCS_SETTING_TYPE_ADV_INTERVAL;
            response[1] = PCS_SET_PARAM_SUCCESS;
            pcs_setting_reply(0, response, 2);
            break;

            ...

        default:
            break;
    }
}
```

### 2. Set advertising data.

Set advertising data, and respond to the peer device based on execution results. The data length can be set to 3, 10, 17, 24, or 31 bytes, which takes effect on the next advertising. For specific code, see processing code of `PCS_SETTING_TYPE_ADV_DATA` event in the `pcs_param_parse()` function.

**Path:** `user_app\user_app.c` under the project directory

**Name:** `pcs_param_parse()`

#### Note:

You need to subtract 3-byte effective length when setting user advertising data by using `ble_gap_adv_param_set()`. This is because Advertising Type Flag occupies 3 bytes of the advertising data.

```
void pcs_param_parse(uint8_t conn_idx, uint8_t *p_data, uint16_t length)
{
```

```

...
case PCS_SETTING_TYPE_ADV_DATA:
    response[0] = PCS_SETTING_TYPE_ADV_DATA;
    response[1] = PCS_SET_PARAM_SUCCESS;

    if (PCS_SET_ADV_DATA_3B == p_data[1])
    {
        s_adv_data_set.length = 0; // 3 byte for adv type
    }
    else if (PCS_SET_ADV_DATA_10B == p_data[1])
    {
        memcpy(s_adv_data_set.adv_data, s_adv_data_10b, 7);
        s_adv_data_set.length = 7; // 3 byte for adv type
    }
    ...
    pcs_setting_reply(0, response, 2);
    break;
    ...
}

```

### 4.2.3 Enabling Notify

If the peer device enables Notify (writing the value 0x0001 to CCCD), the example application starts notifying data after it receives PCS\_EVT\_TX\_ENABLE event; if one data transmission is completed, the example application notifies the data again after it receives PCS\_EVT\_DATA\_SENT, and stops notifying the data when it receives PCS\_EVT\_TX\_DISABLE.

**Path:** user\_app\user\_app.c under the project directory

**Name:** pcs\_service\_event\_process()

```

static void pcs_service_event_process(pcs_evt_t *p_evt)
{
    switch (p_evt->evt_type)
    {
        case PCS_EVT_TX_ENABLE:
            s_is_notify_enable = true;
            pcs_tx_data_notify();
            break;
        case PCS_EVT_TX_DATA_SENT:
            if (s_is_notify_enable)
            {
                s_notify_counter++;
                pcs_tx_data_notify();
            }
            break;
        .....
        default:
            break;
    }
}

```