

GR5xx Throughput Example Application

Version: 3.0

Release Date: 2023-03-30

Shenzhen Goodix Technology Co., Ltd.

Copyright © 2023 Shenzhen Goodix Technology Co., Ltd. All rights reserved.

Any excerption, backup, modification, translation, transmission or commercial use of this document or any portion of this document, in any form or by any means, without the prior written consent of Shenzhen Goodix Technology Co., Ltd. is prohibited.

Trademarks and Permissions

GODIX and other Goodix trademarks are trademarks of Shenzhen Goodix Technology Co., Ltd. All other trademarks and trade names mentioned in this document are the property of their respective holders.

Disclaimer

Information contained in this document is intended for your convenience only and is subject to change without prior notice. It is your responsibility to ensure its application complies with technical specifications.

Shenzhen Goodix Technology Co., Ltd. (hereafter referred to as "Goodix") makes no representation or guarantee for this information, express or implied, oral or written, statutory or otherwise, including but not limited to representation or guarantee for its application, quality, performance, merchantability or fitness for a particular purpose. Goodix shall assume no responsibility for this information and relevant consequences arising out of the use of such information.

Without written consent of Goodix, it is prohibited to use Goodix products as critical components in any life support system. Under the protection of Goodix intellectual property rights, no license may be transferred implicitly or by any other means.

Shenzhen Goodix Technology Co., Ltd.

Headquarters: Floor 12-13, Phase B, Tengfei Industrial Building, Futian Free Trade Zone, Shenzhen, China

TEL: +86-755-33338828 Zip Code: 518000

Website: www.goodix.com

Preface

Purpose

This document introduces how to use and verify a throughput example in the Bluetooth Low Energy (Bluetooth LE) GR5xx Software Development Kit (SDK), to help users quickly get started with secondary development.

Audience

This document is intended for:

- GR5xx user
- GR5xx developer
- GR5xx tester
- Hobbyist developer
- Technical writer

Release Notes

This document is the second release of *GR5xx Throughput Example Application*, corresponding to Bluetooth LE GR5xx System-on-Chip (SoC) series.

Revision History

Version	Date	Description
1.0	2023-01-10	Initial release
3.0	2023-03-30	Updated descriptions about GR5xx SoCs.

Contents

Preface	I
1 Introduction	1
2 Profile Overview	2
2.1 Device Roles	2
2.2 Throughput Service	2
3 Initial Operation	4
3.1 Preparation	
3.2 Firmware Programming	
3.3 Test and Verification	
3.3.1 Test Between SK Board A and a Mobile Phone	
3.3.2 Test Between THS Server and THS Client	8
4 Application Details	
4.1 Project Directory of THS Server	
4.2 Project Directory of THS Client	
4.3 Running Procedures	15
5 Setting THS Parameters on GRUart	16
5.1 Scanning Device	16
5.2 Updating Connection Parameters	16
5.3 Setting MTU	16
5.4 Setting PDU	
5.5 Setting PHY	
5.6 Setting Test Mode	
5.7 Setting TX Power	
5.8 Starting/Stopping Test	



1 Introduction

The GR5xx throughput example in this document demonstrates how link parameters influence the data throughput in Bluetooth Low Energy (Bluetooth LE) connections. These link parameters include Connection Interval, Maximum Transmission Unit (MTU), Data Length, PHY, and TX Power. This example can also verify Bluetooth LE data throughput of GR5xx System-on-Chips (SoCs) in different transfer modes (Notify, Write, and Notify & Write).

This document introduces how to use a throughput example in the GR5xx Software Development Kit (SDK) to verify Bluetooth LE data throughput of GR5xx SoCs.

Before getting started, you can refer to the following documents.

Name	Description
GR5xx Sample Service Application	Introduces how to apply and customize Goodix Sample Service in developing Bluetooth LE
and Customization	applications based on GR5xx SDK.
Developer guide of the specific	Introduces GR5xx SDK and how to develop and debug applications based on the SDK.
GR5xx SoC	introduces GROXX SDR and now to develop and debug applications based on the SDR.
Bluetooth Core Spec	Offers official Bluetooth standards and core specification from Bluetooth SIG.
Plustaath CATT Spac	Provides details about Bluetooth profiles and services. Available at <u>https://www.bluetooth.com/</u>
Bluetooth GATT Spec	specifications/gatt/.
J-Link/J-Trace User Guide	Provides J-Link operational instructions. Available at <u>https://www.segger.com/downloads/jlink/</u>
J-LINKJ-Hace Oser Guide	UM08001_JLink.pdf.
Keil User Guide	Offers detailed Keil operational instructions. Available at https://www.keil.com/support/man/docs/
Nell Osel Guide	<u>uv4/</u> .

Table 1-1	Reference	documents
-----------	-----------	-----------

2 Profile Overview

2.1 Device Roles

Goodix Throughput Profile defines two device roles:

- Throughput Server: Initiate advertising, wait for a connection request from Throughput Client, receive data from Throughput Client, and send data to Throughput Client using Notify.
- Throughput Client: Send a connection request, establish connections with Throughput Server, send data to Throughput Server using Write without Response, and receive data from Throughput Server.

2.2 Throughput Service

Throughput Service interactions between Throughput Server and Throughput Client are shown in Figure 2-1.




Figure 2-1 Server-client interactions

The Throughput Service (THS) is a type of service customized by Goodix. THS is intended for setting the data transfer rate and parameters in THS tests, and the 128-bit vendor-specific UUID of which is A6ED0301-D344-460A-8075-B9E8EC90D71B.

THS characteristics include:

- TX: Send data to THS Client.
- RX: Receive data from THS Client.
- Setting: Receive parameter settings of THS tests, such as MTU, PHY, TX Power, Connection Interval, and Data Length, and notify setting results to THS Client.
- Toggle: Start/Stop THS tests.

THS characteristics are described in Table 2-1.

Table 2-1 THS characteristics

Characteristic	UUID	Туре	Support	Security	Property
тх	A6ED0302-D344-460A-8075- B9E8EC90D71B	128 bits	Mandatory	None	Notify



Characteristic	UUID	Туре	Support	Security	Property
RX	A6ED0303-D344-460A-8075- B9E8EC90D71B	128 bits	Mandatory	None	Write without Response
Setting	A6ED0304-D344-460A-8075- B9E8EC90D71B	128 bits	Mandatory	None	Notify, Write without Response
Toggle	A6ED0305-D344-460A-8075- B9E8EC90D71B	128 bits	Mandatory	None	Write without Response

Three transfer modes are available for THS tests:

- Unidirectional transfer from THS Server: THS Server sends TX characteristic value to THS Client by means of Notify.
- Unidirectional transfer from THS Client: THS Client sends RX characteristic value to THS Server by means of Write without Response.
- Bidirectional transfer between THS Server and THS Client: Simultaneous data transfers between each other are allowed.

In the three transfer modes mentioned above, THS Server receives Setting characteristic value from THS Client to set parameters for THS tests, and notifies setting results to THS Client.

3 Initial Operation

This chapter introduces how to use a throughput example (THS Server and THS Client) in the GR5xx SDK.

🛄 Note:

SDK_Folder is the root directory of the GR5xx SDK in use.

3.1 Preparation

Perform the following tasks before running the GR5xx throughout example.

• Hardware preparation

Table 3-1 Hardware preparation

Name	Description
Development board	Two Starter Kit Boards (SK Boards) of the corresponding SoC
Connection cable	USB Type C cable (Micro USB 2.0 cable for GR551x SoCs)
Android phone	A mobile phone running on Android 5.0 (KitKat) and later

• Software preparation

Table 3-2 Software preparation

Name	Description
Windows	Windows 7/Windows 10
J-Link driver	A J-Link driver. Available at https://www.segger.com/downloads/jlink/.
Keil MDK5	An integrated development environment (IDE). MDK-ARM Version 5.20 or later is required.
	Available at https://www.keil.com/download/product/ .
GRToolbox (Android)	A Bluetooth LE debugging tool. Available in SDK_Folder\tools\GRToolbox.
GProgrammer (Windows)	A programming tool. Available in SDK_Folder\tools\GProgrammer .
GRUart (Windows)	A serial port debugging tool. Available in SDK_Folder\tools\GRUart.

3.2 Firmware Programming

The source code of the GR5xx throughput example is in:

- SDK_Folder\projects\ble\ble_peripheral\ble_app_throughput (for THS Server)
- SDK_Folder\projects\ble\ble_central\ble_app_throughput_c (for THS Client)

You can download *ble_app_throughput.bin* and *ble_app_throughput_c.bin* to the SK Board A (serving as THS Server) and SK Board B (serving as THS Client) respectively through GProgrammer.

For details, see GProgrammer User Manual.

GODIX

🛄 Note:

- ble_app_throughput.bin is in
 SDK_Folder\projects\ble\ble_peripheral\ble_app_throughput\build.
- ble_app_throughput_c.bin is in
 SDK_Folder\projects\ble\ble_central\ble_app_throughput_c\build.

3.3 Test and Verification

In this document, two scenarios are involved in THS tests:

- Scenario 1: Perform a THS test between SK Board A and a mobile phone.
- Scenario 2: Perform a THS test between SK Boards A and B.

3.3.1 Test Between SK Board A and a Mobile Phone

This section introduces how to perform GR5xx THS test and verification between THS Server (SK Board A) and THS Client (an Android phone).

Steps for the test between SK Board A and the mobile phone are described below:

1. Enable the Bluetooth.

Enable the Bluetooth of the mobile phone and power on SK Board A.

2. Scan Goodix THS devices.

Run GRToolbox on the mobile phone and tap **Application** > **THS**.

Start scanning. An SK Board with the advertising name **Goodix_THS** is discovered, as shown in Figure 3-1.




Figure 3-1 Discovering Goodix_THS

Note:

Screenshots of GRToolbox in this document are for reference only, to help users better understand the software operation. In the case of interface differences due to version changes, the interface of GRToolbox in practice shall prevail.

3. Connect Goodix_THS.

Tap and connect **Goodix_THS** to enter the THS test interface, as shown in Figure 3-2.

← 1	THS				:
Goodix_T	'HS		Star	t Test	
CI:7.5ms	MTU:247	PDU:251	PHY:1M	MOD	E:0
Throughp	out	Average kbps		Instant kbps	
1,800					0
1,500					-20
1,200					-40
600					-60
300					-80
	0 20 e — Instant —	30 RSSI	40	50	-100 60
Transmit	Packet				
Total data:		Total	packet:		
Receive P	acket				
Total data:		Total	packet:		
		DISCONNE	CT		

Figure 3-2 THS test interface

4. Set test parameters.

Tap in the upper-right corner of the THS test interface, to enter the test parameter setting interface and configure parameters, as shown in Figure 3-3.

← GRToolbox
Connect Interval 45.0ms
Maximum Transmission Unit 247
Protocol Data Unit 251
Transmission Frequency 2M
Data Tx Mode Notify-Write Cmd
Tx Power OdB

Figure 3-3 Test parameter setting interface

GODIX

5. Start the THS test.

Tap • to start the test. The average value and instant value of Bluetooth LE data throughputs between the mobile phone and the SK Board are displayed in a statistical graph, as shown in Figure 3-4.

← THS			
Goodix_THS		Start	Test 🔵
CI:45.0ms MTU:247	PDU:251	PHY:2M	MODE:2
Throughput	Average 1162kbps		Instant 1239kbps
1,800			0
1,500			-20
900	\checkmark		-40
600			-60
300			-80
0 10 20 — Average — Instant -	30 RSSI	40	-100 50 60
Transmit Packet Total data:1987624		packet:814	6
Receive Packet			
Total data:1980304	Total	packet:811	5
			<
	DISCONNE	СТ)

Figure 3-4 Starting the THS test

3.3.2 Test Between THS Server and THS Client

This section introduces GR5xx THS test and verification between THS Server (SK Board A) and THS Client (SK Board B). Steps for GR5xx THS test and verification are described below:

1. Power on SK Board A and SK Board B.

Power on THS Server (SK Board A) to start advertising.

Power on THS Client (SK Board B) to get ready for scanning THS Server (SK Board A). At this time, "Throughput Service Client example started." is printed on GRUart, as shown in Figure 3-5.



GRUart				- 0	٦	×
-					_	
Vart GLog MultiSend	Rx					
Setting	🗌 Hex 🗹 White 🔲 Time	SaveRx	ClearRev		Sear	ch
☐ HideTx ☐ HideRxPara	APP_I: Goodix BLE SDK APP_I: Local Board EA:CB:3E:CF:01:05. APP_I: Throughput Service Client example start	ed				_
TopMost	In _1. In basipat bervice crient example start	eu.				
TxRx Data Count	Tx					
TxCnt 0 Bytes	Hex NewLine Loop Period 50 🖨 ms					
RxCnt 278 Bytes						
Clear			~	Send	Cle	ear
Port: COM6 BaudRate: 115200	DataBits: 8 StopBit: 1 ParityBit: None CTS=0 DSR=0 DCD=	0				

Figure 3-5 GRUart: getting ready for scanning

2. Start scanning and establish connection with SK Board A.

After the SCAN command is sent via GRUart, SK Board B starts scanning (Figure 3-6). After THS Server (SK Board A) is discovered, SK Board B sends a connection request to SK Board A automatically.



🥘 GRU	art											-	- [×
PortNa	ame: COM6	- (×											
Vart	GLog MultiSe	nd													
Setting			Rx Hex	🗹 White	Time				aveRx	ClearF	eur .			Sear	ch
🗌 Hide	=Tx =RxPara		APP_I: (APP_I: I	Goodix BLE Local Board	SDK 1 EA:CB:3E			10.45		Clear	.ev			Jear	cn
TyRy Do	ita Count		Tx												
TxCnt		Bytes		🗹 NewLine	Loop	Perio	d 50	÷ ns							
RxCnt		Bytes	SCAN												
	Clear		SCAN									~	Send	Cl	ear
Port: CC	M6 BaudRate:	115200	DataBits:	8 StopBit: 1	ParityBit: N	None CTS=	=0 DSR=0	DCD=0							

Figure 3-6 GRUart: scanning device

When THS Client (SK Board B) is connected to THS Server (SK Board A), "Throughput Service discovery completely." is printed on GRUart, and setting of all THS parameter commands starts, as shown in Figure 3-7; for command format, refer to "Chapter 5 Setting THS Parameters on GRUart".

🕘 GRUart				-		Х
PortName: COM6 🗸						
Vart GLog MultiSend						
Setting	Rx 🗹 White 🗌 Time	SaveRx	ClearRev		Sea	rch
☐ HideTx ☐ HideRxPara ☐ TopMost	APP_I: Goodix BLE SDK APP_I: Local Board EA:CB:3E:CF:01:05. APP_I: Throughput Service Client example start APP_I: Start scan device. APP_D: Connected. APP_I: Throughput Service discovery completely APP_I: Enabled TX Notification. APP_I: Enabled SETTING Notification.					
TxRx Data Count	Tx ☐ Hex ✓ NewLine Loop Period ⁵⁰ ♣ ms					
TxCnt 6 Bytes RxCnt 305 Bytes	SCAN					
Clear	SCAN			⊻ Ser	nd C	lear

Figure 3-7 Successful connection interface on GRUart

GODIX

3. Set THS parameters.

Input a corresponding THS parameter setting command (for example, PHY: 0) into GRUart and send the command. The PHY setting interface is shown in Figure 3-8.

🥌 GRUart	- D X
PortName: COM6 -	
Vart GLog MultiSend	
Setting HideTx HideFxPara TopMost	<pre>kx</pre>
TxRx Data Count	Tx □ Hex ✓ NewLine Loop □ Period ⁵⁰ ≑ ms
TxCnt 13 Bytes	☐ Hex ✓ NewLine Loop ☐ Period ⁵⁰ 🕏 ms PHY:0
RxCnt 511 Bytes	
Clear	PHT:0 Send Clear
Port: COM6 BaudRate: 115200	DataBits: 8 StopBit: 1 ParityBit: None CTS=0 DSR=0 DCD=0

Figure 3-8 PHY setting interface

4. Start the THS test.

After all THS parameters are set, send the TOGGLE_SET:1 command via GRUart to start testing, as shown in Figure 3-9.



🖲 GRUart			-	- 0	×
PortName: COM6 -					
Vart GLog MultiSend	Rx .				
Setting		SaveRx	ClearRev	S	earch
HideTx HideRxPara TopMost	<pre>APP_I: Goodix BLE SDK APP_I: Local Board EA:CB:3E:CF:01:05. APP_I: Throughput Service Client example started. APP_I: Start scan device. APP_D: Connected. APP_D: Throughput Service discovery completely. APP_I: Inabled TX Notification. APP_I: Enabled SETTING Notification. APP_I: PHY parameter set completely.</pre>				
Tx <u>R</u> x Data Count	Tx				
TxCnt 27 Bytes	_ Hex ✓ NewLine Loop _ Period ⁵⁰ 🜩 ms				
RxCnt 527 Bytes	TOGGLE_SET: 1		~	Send	Clear
) DataBits: 8 StopBit: 1 ParityBit: None CTS=0 DSR=0 DCD=0			Jenu	ciear .:i

Figure 3-9 Test start interface

The THS test results of SK Board A are displayed on GRUart. An example is shown in Figure 3-10.

🖲 GRUart				- 1	o x
PortName: COM10 🔹					
Vart GLog MultiSend					
Setting HideTx HideRxPara DopMost	Rx Hex White Time APP_I: The instant throughput: 241kbs APP_I: The average throughput: 241kbs(2s)	SaveRx	ClearRev		Search
	APP_I: The instant throughput: 226kbs APP_I: The average throughput: 236kbs(3s) APP_I: The instant throughput: 242kbs APP_I: The average throughput: 237kbs(4s)				
	APP_I: The instant throughput: 241kbs APP_I: The average throughput: 238kbs(5s) APP_I: The instant throughput: 237kbs APP_I: The average throughput: 238kbs(6s)				
	APP_I: The instant throughput: 241kbs APP_I: The average throughput: 238kbs(7s)				
TxRx Data Count	APP I: The instant throughput: 232kbs				¥
TxCnt 0 Bytes RxCnt 2602 Bytes	Hex NewLine Loop Period 50 🖨 ms				
Clear Port: null BaudRate: null Data	Bits: null StopBit: null ParityBit: null CTS=0 DSR=0 DCD=0			✓ Send	Clear

Figure 3-10 THS test results

Parameter descriptions of the THS test results are shown in Table 3-3.



Table 3-3 Parameter description of THS test results

Parameter	Description
instant throughput	Instant throughput
average throughput	Average throughput

To update test parameters during the test, send the TOGGLE_SET: 0 command via GRUart to pause the test and then re-send a parameter setting command.

4 Application Details

This chapter introduces the project directory and running procedures of the THS example (including THS Server and THS Client).

4.1 Project Directory of THS Server

The source code and project file of the THS Server example are in SDK_Folder\projects\ble\ble_periphe ral\ble_app_throughput, and project file is in the Keil_5 folder.

Double-click the project file, *ble_app_throughput.uvprojx*, to view the ble_app_throughput project directory structure of the THS Server example in Keil. For related files, see Table 4-1.

Group	File	Description		
gr_profiles	ths.c	Implements Throughput Service.		
user platform	user periph setup.c	Configures App logs, device address, and power management		
user_plation	user_peripir_setup.c	mode.		
	main.c	Contains the main() function.		
usor ann	user end c	Implements profile registration and logical processing for THS		
user_app	user_app.c	Server applications.		
	throughput.c	Handles THS events.		

Table 4-1 File description	n of ble_ap	p_throughput
----------------------------	-------------	--------------

4.2 Project Directory of THS Client

The source code and project file of the THS Client example are in SDK_Folder\projects\ble\ble_central\ ble_app_throughput_c, and project file is in the Keil_5 folder.

Double-click the project file, *ble_app_throughput_c.uvprojx*, to view the ble_app_throughput_c project directory structure of the THS Client example in Keil. For related files, see Table 4-2.

Group	File Description			
gr_profiles	ths_c.c	Implements Throughput Service Client Profile.		
user platform	user_periph_setup.c	Configures device serial port, device address, and device buttons.		
user_platform	user_interrupt.c	Contains the serial port interrupt handler.		
	main.c	Contains the main() function.		
user_app	user_app.c	Implements profile registration and logical processing for THS Client applications.		
throughput_c.c		Processes Throughput Service Client events and provides throughput statistics.		

Table 4-2 File description of ble_app_throughput_c

4.3 Running Procedures

Interactions between THS Server and THS Client are shown in Figure 4-1:



Figure 4-1 Running procedures

5 Setting THS Parameters on GRUart

During the GR5xx THS test, THS Client receives commands input on GRUart to test related parameters. All input commands should end with a newline ('rn'). The specific command formats are defined as follows.

5.1 Scanning Device

Table 5-1 Scanning command

Command	CAN			
Description	None			
Note	None			
Example	SCAN			
Response	esults from GRUart:			
	Start scanning device.			
	Connected.			
	Throughput Service discovery completes.			
	Enabled TX Notification.			
	Enabled SETTING Notification.			

5.2 Updating Connection Parameters

Table 5-2 Connection parameter update command

Command	CI: <conn_interval_min>:<conn_interval_max>:<latency>:<timeout></timeout></latency></conn_interval_max></conn_interval_min>			
Description	conn_interval_min>: minimum value of connection interval (unit: 1.25 ms)			
	<conn_interval_max>: maximum value of connection interval (unit: 1.25 ms)</conn_interval_max>			
	<latency>: connection latency</latency>			
	<timeout>: connection timeout (unit: 10 ms)</timeout>			
Note	If a fixed connection interval is required, set the maximum and the minimum connection intervals to the same			
	value.			
	For tests on optimal throughput, set the latency value to 0.			
	Timeout > (1 + Latency) x conn_interval x 2			
Example	CI:12:12:0:100			
Response	Setting results from GRUart			

5.3 Setting MTU

Table 5-3 MTU setting command

Command	MTU: <mtu_value></mtu_value>		
---------	------------------------------	--	--

GODIX

Setting THS Parameters on GRUart

Description	<mtu_value>: MTU; value range: 23 to 512</mtu_value>
Example	MTU: 247
Response	Setting results from GRUart

5.4 Setting PDU

Table 5-4 PDU setting command

Command	PDU: <payload_octets>:<time></time></payload_octets>
Description	<payload_octets>: payload octets</payload_octets>
	< time >: time for TX
Note	None
Example	PDU:251:2120
Response	Setting results from GRUart

5.5 Setting PHY

Command	PHY: <tx_phy>:<rx_phy>:<phy_opt></phy_opt></rx_phy></tx_phy>
Description	<tx_phy>: Preferred transmit PHYs</tx_phy>
	• 1: 1M PHY
	• 2: 2M PHY
	• 4: Coded PHY
	<rx_phy>: Preferred receive PHYs</rx_phy>
	• 1: 1M PHY
	• 2: 2M PHY
	• 4: Coded PHY
	< phy_opt >: Options for PHY
	• 0: Host has no preferred coding when transmitting on the LE Coded PHY.
	• 1: Host prefers that S=2 coding be used when transmitting on the LE Coded PHY.
	• 2: Host prefers that S=8 coding be used when transmitting on the LE Coded PHY.
Note	None
Example	PHY:1:1:0
Response	Setting results from GRUart

5.6 Setting Test Mode

Table 5-6 Test mode setting command

Command	TRANS_MODE: <mode></mode>
Description	<mode>: test mode</mode>
	0: Send data from THS Server only (Notify).
	1: Send data from THS Client only (Write).
	2: Send data from both THS Server and THS Client.
Note	None
Example	TRANS_MODE: 2
Response	Setting results from GRUart

5.7 Setting TX Power

Table 5-7 TX Power setting command

Command	TX_PWR: <tx_power_value></tx_power_value>
Description	<tx_power_value>: TX power value; options: "-20", "-4", "0", "2", "4", "7"</tx_power_value>
Note	None
Example	TX_PWR:2
Response	Setting results from GRUart

5.8 Starting/Stopping Test

Table 5-8 Test start/stop command

Command	TOGGLE_SET: <start_or_stop></start_or_stop>
Description	< start_or_stop >: Start or stop the test.
	0: Stop the test.
	1: Start the test.
Note	None
Example	TOGGLE_SET: 1
Response	Setting results from GRUart